



# TROWEL-GLIDE

## PRODUCT NAME

### TROWEL-GLIDE

MANUFACTURER & DISTRIBUTOR  
OF INDUSTRIAL CHEMICALS  
1611 GUNN HIGHWAY  
ODESSA, FLORIDA 33556  
(813) 886-8811

## PRODUCT DESCRIPTION

TROWEL-GLIDE is an easy-to-use waterbase wax emulsion used to smooth concrete finishes and reduce the chance of surface cracking. The use of TROWEL-GLIDE will also create a monomolecular invisible film to prevent rapid moisture loss from the concrete surface during high temperatures, extreme wind and low humidity.

## BENEFITS

- Enhances ability to create a smooth trowelled surface.
- Reduces stickiness when working with overlay systems.
- Extends surface finishing time, making finishing easier under harsh ambient conditions.
- Surface crusting can be reduced or eliminated, allowing easier troweling of concrete surfaces.
- Will not effect bonding of cures or coatings, nor alter the final color of the concrete

## RECOMMENDED USES

- For use on any cementitious trowelled surface when a smooth finish is desired.

## INSTRUCTIONS FOR USE

Mixing:  
TROWEL-GLIDE should be mixed 10 parts water to 1 part TROWEL-GLIDE.

## Application:

Immediately after gauge raking, apply mixed TROWEL-GLIDE with a pump sprayer.

## COVERAGE

Application Conditions	Coverage Rate (ft <sup>2</sup> /gal)
Normal Conditions	250-350
Warm, no wind	200-300
Hot, drying winds	150-250

## STORAGE AND HANDLING

TROWEL-GLIDE should be stored indoors and, when left in its original unopened package will maintain its designed performance characteristics for 12 months.

## LIMITATIONS/WARNINGS

- Not to be used as a curing compound.
- Do not allow to freeze.
- Not recommended for use during cool or wet conditions.

## PACKAGING

1 gallon, 5 gallon pail, 55 gallon drum

## AVAILABILITY

Available through distributors or contact manufacturer.

## TECHNICAL INFORMATION

Refer to material safety data sheet.

## SAFETY PRECAUTIONS

Always wear protective eye goggles and gloves when using this product. Do not take internally. If swallowed, do not induce vomiting. Contact a physician immediately. If eye contact occurs, flush eyes with fresh water for 15 minutes and contact physician. Wash all exposed area with soap and water after use. Keep out of reach of children.

## IMPORTANT NOTICE

THESE PRODUCTS ARE SOLD SUBJECT ONLY TO THE EXPRESSED WARRANTIES CONTAINED HEREIN. ADDITIONAL WARRANTIES, EXPRESSED OR IMPLIED, AND ANY WARRANTY OF MERCHANT ABILITY IS HEREBY EXCLUDED. BUYER AGREES THAT SELLER ASSUMES NO LIABILITY FOR CONSEQUENTIAL DAMAGES OF ANY KIND, WHICH RESULT FROM THE USE OR MISUSE OF THE MERCHANDISE SOLD HEREUNDER. IN THE EVENT THAT THE BUYER PROVES THAT ANY GOODS RECEIVED DO NOT CONFORM TO THE SPECIFICATIONS AGREED TO BETWEEN THE PARTIES OR IF THE BUYER PROVES THAT SUCH GOODS WERE DEFECTIVELY MANUFACTURED. THE BUYER'S REMEDIES SHALL BE LIMITED TO EITHER THE RETURN OF THE GOODS AND REPAYMENT OF THE PURCHASE PRICE OR REPLACEMENT OF THE NON-CONFORMING GOODS AT THE OPTION OF THE SELLER. SUCH REMEDY BEING EXCLUSIVE OF ALL OTHERS AND THE SOLE REMEDY AVAILABLE TO THE BUYER, HEREBY EXPRESSLY WAIVES ANY CLAIM TO ADDITIONAL DAMAGES.

**WARRANTY**

All recommendations, statements and technical data contained herein based on tests we believe to be reliable and correct, but accuracy and completeness of said tests are not guaranteed and are not to be construed as a warranty, either expressed or implied. User shall rely on his own information and tests to determine suitability of the product for the intended use and user assumes all risk and liability resulting from his use of the product of this manufacturer which proves to be defective. Neither seller nor manufacturer shall be liable to the buyer or any third person having any injury, loss or damage directly or indirectly resulting from use of or inability to use the product. Recommendations or statements other than those contained in written agreement signed by an officer of the manufacturer shall not be binding upon the manufacturer or seller.